

INTRODUCTION TO DISTANCE SENSOR

BY SANJAY AND ARVIND SESHAN

LESSON OBJECTIVES

- Learn how to use the Distance Sensor
- Learn how to use the Wait Until Block
- Note: Although images in this lessons may show a SPIKE Prime, the code blocks are the same for Robot Inventor



WHAT IS A DISTANCE SENSOR?


- Measures the distance to an object or surface using ultrasonic technology
- There are also lights around the ultrasonic sensor (4 segments) that can be programmed individually (see Lights Lesson)
- The sensor can sense distances from 50-2000mm
- There is a fast sensing capability from 50-300mm



HOW DO YOU PROGRAM WITH A DISTANCE SENSOR

- The Distance Sensor can measure the distance to an object or surface using ultrasonic
- You can also program the lights around the sensor. This is covered in a different lesson.
- Units can be measured in Percent, Centimeters or Inches






CHALLENGE: AWAY FROM THE WALL

- You want to find the opening. Use your Distance Sensor (mounted on the side of the robot like Droid Bot IV) to locate the gap
- Program your robot to move straight until it is less than 20cm from the wall
- You will need to use the Wait For block and the Boolean block of the Distance Center






- Set the **movement motors** for your robot (A and E for ADB robot)
- Set the % speed for your robot
- Start moving straight
- Use the wait for block to detect that it is less than 20cm from the wall
- Stop moving




CHALLENGE I: SOLUTION



Wait until the Distance sensor is less than 20cm

EXTENSION

Once you find the wall, move the robot backwards and go through the hole



CREDITS

- This lesson was created by Sanjay Seshan and Arvind Seshan for Prime Lessons
- More lessons are available at www.primelessons.org



This work is licensed under a <u>Creative Commons Attribution-NonCommercial-ShareAlike 4.0 International</u> License.